



- 3 PLACE TEMP COMPENSATION TRANSISTOR ON THE BACKSIDE OF THE BOARD DIRECTLY UNDER OUTPUT INDUCTOR
- 2 CONNECT ACROSS PINS OF OUTPUT INDUCTOR
- 1 MINIMUM 1K LOAD REQUIRED. MUST BE CONNECTED BEFORE SENSE RESISTOR TO AVOID CONTRIBUTION TO CURRENT MEASUREMENTS.